AC loads showing no current flow but critical shows load current? what settings are required

From:
https://www.victronenergy.com/live/ - **Victron Energy**

Permanent link:
https://www.victronenergy.com/live/ac_load_showing_no_current

Last update: **2019-01-22 10:42**